

High Performance Cold Air Intake Kit



INSTALLATION INSTRUCTIONS

75-9014-1

**Toyota Tundra
V8 4.7L**

QTY	PARTS LIST	QTY	PARTS LIST	QTY	PARTS LIST
1	3.25" - 2" Adapter	2	#52 Hose Clamps	4	SS Pan Head Screws
1	3/8" x 16" Hose	1	1/4" x 1/4" Hose Barb - NPT	1	Air Filter
1	3/16" x 18" Hose	1	3/8" x 1/4" Hose Barb - NPT		
1	5/16" x 21" Hose	3	1/4" Washers		
1	Intake Tube	1	Stick On Gasket		
1	Intake Box	1	3/16" x 1.25" Hose Barb		
1	Intake Lid	1	5/16" x 1/4" Hose Barb		
1	CARB Sticker	3	M6 Hex Head Screws		
1	Instruction Sheet	4	Sealing Washers		

TOOLS REQUIRED

- 10mm, 12mm socket
- Long ratchet extension
- Flat & Phillips head screwdriver

- Turn off engine and disconnect negative battery terminal.
- Disconnect the mass air sensor electrical connection
- Release the electrical route clip on the resonator box
- Remove the throttle body shield
- Loosen the 3 bolts that screw the stock air box to the fender
- Loosen the hose clamp on the stock intake tube at the throttle
- Disconnect all of the vacuum hoses from the resonator box
- Remove the entire air intake system from the vehicle
- Loosen and remove the mass air sensor from the stock air box. Do not lose the small screws they will be re-used



INSTALLATION INSTRUCTIONS (continued)

10. Attach the provided gasket onto the mass air sensor. Sticky side toward the sensor base.



11. Install the mass air sensor into the S&B cold air tube



12. Attach the throttle body adaptor cuff to the S&B cold air tube. Install the hose barb fittings in the order shown and tighten all barbs and hose clamps



13. Install the S&B cold air box and tighten the box



14. Install the S&B cold air tube thru the air box and attach it to the throttle body. Leave the hose clamp "semi tight for adjustment



15. Slide the hose clamp that secures the filter onto the S&B cold air tube



16. Connect the S&B high performance filter to the S&B cold air tube. Push the filter tight against the wall of the box. Tighten the hose clamps for the filter. Tighten the hose clamps for the cold air tube



17. Connect all of the vacuum hoses as shown



18. Connect the mass air sensor electrical connection



19. Attach the A.C. hose to the S&B cold air intake tube.



20. Re-attach the throttle body cover. Secure the air box lid to the S&B cold air box. Reconnect the negative side of the battery.



PERFORMANCE TESTING

- * Engage parking brake and start your engine. To ensure that the system was installed properly, listen for abnormal noises. If an air leak is detected, re-inspect hoses and connections as they may need to be tightened.
- * S&B FILTERS RECOMMENDS THAT YOU KEEP YOUR OEM INTAKE SYSTEM IN THE EVENT IT IS REQUIRED IN THE FUTURE.
- * In order to maintain proper warranty, all connections and components must be checked periodically for re-alignment and to tighten all connections. Failure to do so will void your warranty.
- * Use only S&B cleaning and oil products to service your filter. Using other company's oil and cleaner products may void your warranty.

Please call (909) 947-0015 should you have any questions or comments.